

```

=====
# Configuration File Version - 10.10.00
#-----

#=====
# Folder Location Definition - DO NOT CHANGE
#-----
# The CIVIL_ORGANIZATION_STANDARDS variable defines where the Organization Standards
# are located. These can be located on a local computer or a shared network drive.
# To define these on a network drive, edit the WorkSpaceSetup.cfg file and change
# the CIVIL_ORGANIZATION_ROOT variable. NO changes are needed in this file.

```

```

CIVIL_ORGANIZATION_STANDARDS = $(CIVIL_ORGANIZATION_ROOT)$(CIVIL_ORGANIZATION_NAME)/
#-----

```

```

#=====
# Preferences files
#-----
_USTN_USERNAME           = $_USTN_PRODUCT_SHORTNAME_$(CIVIL_FILENAME)
_USTN_PREFNAMEBASE       = $_USTN_HOMEPREFIX$_USTN_PRODUCT_SHORTNAME_$(CIVIL_FILENAME)
MS_DOCKINGPREF           = $_USTN_PREFNAMEBASE).docking.xml
MS_GROUPPANELPREF        = $_USTN_PREFNAMEBASE).GroupPanels.xml
MS_SAVEMENU              = $_USTN_PREFNAMEBASE).Attached.mer
MS_RIBBONPREFS           = $_USTN_PREFNAMEBASE).RibbonState.xml
MS_FKEYMNU              = $_USTN_PREFNAMEBASE).funkey.mnu
MS_USERPREF              = $_USTN_PREFNAMEBASE).upl
#-----

```

```

#=====
# Seed files (Additional Seed files defined in the Subsurface Utilities section)
#-----

MS_SEEDFILES             = $(CIVIL_ORGANIZATION_STANDARDS)Seed/
MS_DESIGN                = Project Design Seed 2d.dgn
MS_DESIGNMODELSEED       = Project Design Seed 2d.dgn
MS_DESIGNMODELSEEDNAME   = Default
MS_DRAWINGMODELSEED      = Drawing Seed 2d.dgn
MS_DRAWINGMODELSEEDNAME  = 2D Drawing
MS_SHEETMODELSEED        = Sheet Seed 2d.dgn
MS_SHEETMODELSEEDNAME    = 2D Sheet

MS_CELL_SEEDFILE         = Seed2D - $(CIVIL_FILENAME) Design.dgn
#-----

```

```

#=====
# CAD Environment (MicroStation) OpenSite/OpenRoads/OpenRail Designer DGN Library Settings
#-----
# MS_LEVEL_LIB_DIR        Directory to look for when exporting levels or importing levels to/from a CSV, DGN, or DGNLib file
# MS_DGNLIBLIST           DGN library files that define Levels, Line Styles, Text Styles, Dimension Styles, Multiline Styles
#                          Element Templates, Text Favorites, Table Styles, Report Definitions, Drawing Seeds, Drawing Boundaries,
#                          Display Styles, Display Rules, Page Layouts, Saved Views and Item Types
# MS_DGNLIBLIST_LEVELS    Specific DGN library files that define levels. Level definitions in all other DGN library files are ignored
# MS_DGNLIBLIST_TEXTSTYLES Specific DGN library files that define text styles. Text styles definitions in all other DGN library files are ignored
# MS_DGNLIBLIST_TEXTFAVORITES Specific DGN library files that define text favorites. Text favorites definitions in all other DGN library files are ignored
# MS_DGNLIBLIST_DIMENSIONSTYLES Specific DGN library files that define dimension styles. Dimension styles definitions in all other DGN library files are ignored
#
# CIVIL_CONTENTMANAGEMENTDGNLIBLIST Specific DGN library files that civil feature definitions.
# CIVIL_PROJECTSETTINGSDGNLIBLIST Specific DGN library files that civil survey settings.
# RAIL_SETTINGSDGNLIBLIST Specific DGN library files that civil rail settings.
#
# CIVIL_LABELER_XMLFILE   The XML file where civil labels are defined
#
# MS_ALLOWREADONLYITEMEDIT When set to TRUE, makes item types from references within the same file editable. For example, when
#                          an item type is on a 3d element. Selecting the 2d element in the 2d model will show the item type or
#                          the 3d element as read only if this variable is not set
# MS_DGNLIBLIST_ITEMTYPES Specific DGN library files that define item types. Item type definitions in all other DGN library files are ignored
# ITEMTYPE_LOOKUP         The excel file(s) where lookup expressions AND pick lists are defined for item types. Multiple files can be defined
# ITEMTYPE_PICKLIST_EXCELPATH The excel file(s) where item type pick lists are defined IF they are in a different file than the lookup expressions
#                          If the pick lists and lookup expressions are in the same file, only use the ITEMTYPE_LOOKUP variable
# ITEMTYPE_PRIORITY_MAP_PATH <OPTIONAL> A single json file that defines behavior for resolving item type conflicts
#                          When this file is not defined the value from the FIRST element selected is used if there is a conflict. Using this file
#                          the behavior can be set to use the FIRST, LAST, or NONE for each command
#-----

```

```

# The following are common to OpenSite, OpenRoads, OpenRail, Overhead Line, or OpenBridge and are always loaded
# MS_LEVEL_LIB_DIR        < $(CIVIL_ORGANIZATION_STANDARDS)Dgnlib/Feature Definitions/
# MS_DGNLIBLIST           < $(CIVIL_ORGANIZATION_STANDARDS)Dgnlib/Feature Definitions/*.dgnlib
# MS_DGNLIBLIST_LEVELS    < $(CIVIL_ORGANIZATION_STANDARDS)Dgnlib/Feature Definitions/*Levels*.dgnlib
# CIVIL_CONTENTMANAGEMENTDGNLIBLIST > $(CIVIL_ORGANIZATION_STANDARDS)Dgnlib/Feature Definitions/*Features*.dgnlib
# MS_DGNLIBLIST_TEXTSTYLES < $(CIVIL_ORGANIZATION_STANDARDS)Dgnlib/Feature Definitions/*Text Styles*.dgnlib
# MS_DGNLIBLIST_TEXTFAVORITES < $(CIVIL_ORGANIZATION_STANDARDS)Dgnlib/Feature Definitions/*Text Favorites*.dgnlib
# MS_DGNLIBLIST_DIMENSIONSTYLES < $(CIVIL_ORGANIZATION_STANDARDS)Dgnlib/Feature Definitions/*Dimension Styles*.dgnlib
# CIVIL_PROJECTSETTINGSDGNLIBLIST > $(CIVIL_ORGANIZATION_STANDARDS)Dgnlib/Feature Definitions/*Survey Settings*.dgnlib
# MS_DGNLIBLIST           > $(CIVIL_ORGANIZATION_STANDARDS)Dgnlib/Sheet Seeds/*.dgnlib
# CIVIL_LABELER_XMLFILE   = $(CIVIL_ORGANIZATION_STANDARDS)Dgnlib/Feature Definitions/Civil Labeler $(UNITS).xml

# Item Types
MS_ALLOWREADONLYITEMEDIT = TRUE

```

NEW UPRR CIVIL CAD STANDARDS
 MIGRATED FROM V8i CAD STANDARDS
 COPIED FROM BENTLEY TEMPLATE
 MODIFIED FROM BENTLEY TEMPLATE
 TO CONFORM TO UP STANDARD

```

MS_DGNLIBLIST_ITEMTYPES = $(CIVIL_ORGANIZATION_STANDARDS)Dgnlib/Feature Definitions/*Item Types*.dgnlib
ITEMTYPE_LOOKUP = $(CIVIL_ORGANIZATION_STANDARDS)Dgnlib/Item Types/Pay Item Lookup.xlsx
ITEMTYPE_LOOKUP > $(CIVIL_ORGANIZATION_STANDARDS)Dgnlib/Item Types/Sign Lookup.xlsx
ITEMTYPE_LOOKUP > $(CIVIL_ORGANIZATION_STANDARDS)Asset Manager/Asset Management Lookup.xlsx
ITEMTYPE_PRIORITY_MAP_PATH = $(CIVIL_ORGANIZATION_STANDARDS)Dgnlib/Item Types/Civil Item Type Priority.json

# Add the following if running OpenRoads, OpenRail, Overhead Line, or OpenBridge
%if $( _ENGINE_NAME) == "OpenRoadsDesigner" || $( _ENGINE_NAME) == "OpenRailDesigner" || $( _ENGINE_NAME) == "OpenRailOverheadLineDesigner" || $( _ENGINE_NAME) == "OpenBridgeModeler"
MS_DGNLIBLIST < $(CIVIL_ORGANIZATION_STANDARDS)Dgnlib/Feature Definitions/Road/*.dgnlib
MS_DGNLIBLIST_LEVELS < $(CIVIL_ORGANIZATION_STANDARDS)Dgnlib/Feature Definitions/Road/*Levels*.dgnlib
CIVIL_CONTENTMANAGEMENTDGNLIBLIST > $(CIVIL_ORGANIZATION_STANDARDS)Dgnlib/Feature Definitions/Road/*Features*.dgnlib
MS_DGNLIBLIST_TEXTSTYLES < $(CIVIL_ORGANIZATION_STANDARDS)Dgnlib/Feature Definitions/Road/*Text Styles*.dgnlib
MS_DGNLIBLIST_TEXTFAVORITES < $(CIVIL_ORGANIZATION_STANDARDS)Dgnlib/Feature Definitions/Road/*Text Favorites*.dgnlib
MS_DGNLIBLIST_DIMENSIONSTYLES < $(CIVIL_ORGANIZATION_STANDARDS)Dgnlib/Feature Definitions/Road/*Dimension Styles*.dgnlib
%endif

# Add the following if running OpenRail, Overhead Line, or OpenBridge
%if $( _ENGINE_NAME) == "OpenRailDesigner" || $( _ENGINE_NAME) == "OpenRailOverheadLineDesigner" || $( _ENGINE_NAME) == "OpenBridgeModeler"
MS_DGNLIBLIST < $(CIVIL_ORGANIZATION_STANDARDS)Dgnlib/Feature Definitions/Rail/*.dgnlib
MS_DGNLIBLIST_LEVELS < $(CIVIL_ORGANIZATION_STANDARDS)Dgnlib/Feature Definitions/Rail/*Levels*.dgnlib
CIVIL_CONTENTMANAGEMENTDGNLIBLIST > $(CIVIL_ORGANIZATION_STANDARDS)Dgnlib/Feature Definitions/Rail/*Features*.dgnlib
MS_DGNLIBLIST_TEXTSTYLES < $(CIVIL_ORGANIZATION_STANDARDS)Dgnlib/Feature Definitions/Rail/*Text Styles*.dgnlib
MS_DGNLIBLIST_TEXTFAVORITES < $(CIVIL_ORGANIZATION_STANDARDS)Dgnlib/Feature Definitions/Rail/*Text Favorites*.dgnlib
MS_DGNLIBLIST_DIMENSIONSTYLES < $(CIVIL_ORGANIZATION_STANDARDS)Dgnlib/Feature Definitions/Rail/*Dimension Styles*.dgnlib
RAIL_SETTINGSDGNLIBLIST < $(CIVIL_ORGANIZATION_STANDARDS)Dgnlib/Feature Definitions/Rail/*Rail Settings*.dgnlib
MS_DGNLIBLIST > $(CIVIL_ORGANIZATION_STANDARDS)Dgnlib/Sheet Seeds/Rail/*.dgnlib
%endif

# Add the following if running Overhead Line
%if $( _ENGINE_NAME) == "OpenRailOverheadLineDesigner"
MS_DGNLIBLIST_LEVELS < $(CIVIL_ORGANIZATION_STANDARDS)Dgnlib/Feature Definitions/Rail Overhead Line/*Levels*.dgnlib
MS_CELLLIST > $(CIVIL_ORGANIZATION_STANDARDS)cell/Rail Overhead Line/*.cel # Cell Libraries to be searched
%endif
#-----

```

```

#-----
# General CAD Environment (MicroStation) Settings
#-----
MS_DGNLIBLIST > $(CIVIL_ORGANIZATION_STANDARDS)Dgnlib/Line Styles/*.dgnlib # Location of Line Style:
MS_SYMBRSRC > $(CIVIL_C # EDIT LOCATION OF LINESTYLES
MS_FONTPATH > $(CIVIL_ORGANIZATION_STANDARDS)fonts/ # Location of MicroStation font
MS_DGNTEXTEDITORFAVORITESYMBOLS = $(CIVIL_ORGANIZATION_STANDARDS)fonts/FavoriteSymbols.xml # Location and name of text favorites symbol:
MS_DGNLIBLIST > $(CIVIL_ORGANIZATION_STANDARDS)Dgnlib/Display Styles/*.dgnlib # Location of Display Styles
MS_GUIDGNLIBLIST > $(CIVIL_ORGANIZATION_STANDARDS)Dgnlib/GUI/*.dgnlib # Location of GUI Customization seeds:
MS_COLORBOOK_LIBRARIES < $(CIVIL_ORGANIZATION_STANDARDS)Dgnlib/Color Books/*.dgnlib # Location of for Color Book:
MS_CELL < $(CIVIL_ORGANIZATION_STANDARDS)cell/ # Location of Cell Libraries
MS_CELLLIST < $(CIVIL_ORGANIZATION_STANDARDS)cell/*.cel # Cell Libraries to be searched
MS_MATERIAL < $(CIVIL_ORGANIZATION_STANDARDS)materials/ # Location of material pallet
MS_PATTERN < $(CIVIL_ORGANIZATION_STANDARDS)materials/pattern/ # Location of pattern map:
MS_BUMP < $(CIVIL_ORGANIZATION_STANDARDS)materials/bump/ # Location of bump map
MS_CUSTOMSCALEDDEF = $(CIVIL_ORGANIZATION_STANDARDS)Scales/scales.def # Scale Definitions used for Annotation Scale:
MS_CUSTOMUNITDEF = $(CIVIL_ORGANIZATION_STANDARDS)Scales/units.def # Units Definitions used for Custom Unit:
MS_CUSTOMSHEETSIZEDEF = $(CIVIL_ORGANIZATION_STANDARDS)Scales/sheet sizes.def # Sheet Size Definitions used for Sheet Size:
MS_PLTCFG_PATH = $(CIVIL_ORGANIZATION_STANDARDS)Plot/
MS_DEFAULT_PLTCFG_FILE = $(MS_PLTCFG_PATH)11x17c_pdf.pltcfg
MS_DGNLIBLIST_PRINTING > $(CIVIL_ORGANIZATION_STANDARDS)Dgnlib/Print/*.dgnlib
MS_DGNLIBLIST > $(CIVIL_ORGANIZATION_STANDARDS)Dgnlib/Print/*
MS_PENTABLE = $(MS_PLTCFG_PATH)Pen Tables/ # EDIT Default location for pen tables
MS_PLOTDLG_DEF_PENTABLE = $(MS_PLTCFG_PATH)Pen Tables/UPRR Track Pentable.tbl

```

```

MS_DGNLIBLIST > $(CIVIL_ORGANIZATION # EDIT Default location for report tables
MS_BACKUP = $( _DGNDIR) # Directory for backup file
MS_REPORT_OUTPUT = $( _DGNDIR) # Default output directory where MicroStation
# report (not OpenRoads/OpenRail) results will be exported
MS_VIEWAUTORESIZ = 1 # If set to 1, the view windows are resized proportionally when the
# main window is resized or when the dialogs are docked or undocked
_ USTN_DISPLAYALLCFGVARS = 1 # If set to 1, display all hidden variables:
MS_FULLPATHINTITLEBAR = 1 # If set to 1, show the full file name path in the title bar
MS_CURSORPROMPT = 1 # If set to 1, show the prompt field on the cursor
#-----

# Visual Basic Settings
#-----
MS_VBSEARCHDIRECTORIES > $(CIVIL_ORGANIZATION_STANDARDS)Macros/ # Location of visual basic applications

# Viewset utility which provides convenient view control options for civil design.
MS_VBAUTOLOADPROJECTS > $(CIVIL_ORGANIZATION_STANDARDS)Macros/ViewSet # Load the Viewset utility.
VIEWSET_SETTINGS_FILE = $(CIVIL_ORGANIZATION_STANDARDS)Macros/ViewControlConfigurations.xml # Configuration for the Viewset utility

# Snappable Toggle utility which uses the Ctrl+F1 and Ctrl+F2 function keys to turn on or off the
# specified levels and enable or disable the snappability of the particular elements. This is useful
# when annotating the drawing models of cross sections or profiles where the grid lines may be in the way.
MS_VBAUTOLOADPROJECTS > $(CIVIL_ORGANIZATION_STANDARDS)Macros/SnappableToggle # Load the Snappable Toggle utility
CIVIL_SNAPPABLETOGGLE_LEVELS_FILE = $(CIVIL_ORGANIZATION_STANDARDS)Macros/SnappableToggle_Levels.txt # Configuration for the Snappable Toggle utility
#-----

```

```

#=====
# Reference File Paths and Settings
#=====
MS_REF_DEFAULTATTACHDIRECTORY    = $_DGNDIR
MS_REF_DEFAULTSETTINGS           = TrueScale=1,AttachMethod=CoincidentWorld,nestMode=live,NestDepth=0,SaveRelativePath=1
MS_RFDIR                         > $_DGNDIR
MS_RFDIR                         > $(CIVIL_ORGANIZATION_STANDARDS)Sheet Borders/
MS_REF_MASTERFILELAST_DESIGN     = 1
MS_REF_NEWLEVELDISPLAY           = 1
MS_REF_VISEGE_ATTACH_STATE       = Dynamic
#MS_DISALLOWFULLREFPATH          = 1
#-----

#=====
# General OpenSite/OpenRoads/OpenRail Settings
#=====
CIVIL_CIVILTM DGNLIBLIST         > $(CIVIL_ORGANIZATION_STANDARDS)Dgnlib/Graphical Filters/*.dgnlib  # Location of Graphical Filters
CIVIL_CIVILCELL DGNLIBLIST       > $(CIVIL_ORGANIZATION_STANDARDS)Dgnlib/Civil Cells/*.dgnlib    # Location of Civil Cells
CIVIL_DESIGNSTANDARDS DGNLIBLIST > $(CIVIL_ORGANIZATION_STANDARDS)Dgnlib/Design Standards/*.dgnlib    # Location of Design Standards
MS_ACCUDRAWKEYS                  = $_USTN_HOMEPREFS                                           # Location of Civil AccuDraw (not AccuDraw) settings and favorite
CIVIL_SUPERELEVATION_RULES_DIRECTORY = $(CIVIL_ORGANIZATION_STANDARDS)Superelevation/          # Location of Superelevation rule file:
CIVIL_SUPERELEVATION_RULE_FILE    = $(CIVIL_SUPERELEVATION_RULES_DIRECTORY)AASHTO_2018_imperial.xml # Default Superelevation rule file
CIVIL_SIGHTVISIBILITY_SETTINGS_DIRECTORY = $(CIVIL_ORGANIZATION_STANDARDS)Sight Visibility/      # Location of Site Visibility settings file
CIVIL_REPORTS_SUBDIRECTORIES     > $(CIVIL_ORGANIZATION_STANDARDS)Reports/                  # Location of Report XML Files. Custom reports will be shown
#                                in addition to the default reports from the \Program Files\ folder
CIVIL_DEFAULT_STATION_LOCK        = TRUE                                                       # Station Lock - If set to TRUE then stations for various commands
#                                are adjusted to stay at even values. For example, template drop
#                                will adjust to be at even stations in the event of an equation
#                                that could cause it to do otherwise. If not set or set to FALSE
#                                then the station values will be maintained at the specified increment
#CIVIL_CIVILSETTINGS_READONLY     = 1                                                           # If set to 1, standards, preferences and features that come from a DGN Library
#                                are persisted as Read-only. If variable is not Defined, items are persisted
#                                as Read-Write. If set to 1, items are persisted as Read-only
%if exists $( _USTN_WORKSETSTANDARDS)Cell/ )
    CIVIL_COMPONENTCENTER_DOWNLOADEDCELLSLIB = $( _USTN_WORKSETSTANDARDS)Cell/Downloaded Component Center Cells.cel
%else
    CIVIL_COMPONENTCENTER_DOWNLOADEDCELLSLIB = $(MS_DEF)/Downloaded Component Center Cells.cel
%endif
#-----

```

```

#=====
# Template Library #EDITS BELOW
#=====
%if $( _ENGINE_NAME) == "OpenSiteDesigner"
    #CIVIL_ROADWAY_TEMPLATE_LIBRARY = $(CIVIL_ORGANIZATION_STANDARDS)Template Library/OpenSite Templates $(CIVIL_FILENAME).itl
%elif $( _ENGINE_NAME) == "OpenRoadsDesigner"
    #CIVIL_ROADWAY_TEMPLATE_LIBRARY = $(CIVIL_ORGANIZATION_STANDARDS)Template Library/OpenRoads Templates $(CIVIL_FILENAME).itl
%else
    #CIVIL_ROADWAY_TEMPLATE_LIBRARY = $(CIVIL_ORGANIZATION_STANDARDS)Template Library/OpenRail Templates $(CIVIL_FILENAME).itl
%endif

CIVIL_ROADWAY_TEMPLATE_LIBRARY = $(CIVIL_ORGANIZATION_STANDARDS)Template Library/Rail Templates.itl

```

```

#=====
# Drainage and Utilities
#=====
# SUDA_SEED_FILE defines a dgnlib file that contains the default hydraulic settings.
# SUDA_SEED_MODEL defines the model to read from the dgnlib file. The information in this mode
# is copied to the active dgn when you first use Drainage and Utilities. The information in this
# model normally includes hydraulics and hydrology settings, as well as feature definitions.
SUDA_SEED_FILE      = $(CIVIL_ORGANIZATION_STANDARDS)Dgnlib/Feature Definitions/Drainage and Utilities Features Annotations $(CIVIL_FILENAME).dgnlib
SUDA_SEED_MODEL     = Default

# SUE_SEED_FILE defines a dgnlib file that contains the default subsurface utility settings.
# SUE_SEED_MODEL defines the model to read from the dgnlib file. The information in this mode
# is copied to the active dgn when you first use a Drainage and Utilities. The information in this
# model normally includes subsurface utilities settings, as well as feature definitions.
SUE_SEED_FILE      = $(CIVIL_ORGANIZATION_STANDARDS)Dgnlib/Feature Definitions/Drainage and Utilities Features Annotations $(CIVIL_FILENAME).dgnlib
SUE_SEED_MODEL     = Default

# SUDA_USE_HAESTAD_CONDUIT tells hydraulic conduits to forget about the sizes that are stored
# in the feature definition, and use the sizes that are stored in the Haestad conduit library.
SUDA_USE_HAESTAD_CONDUIT = 1

# CIVIL_SUBSURFACE_FILTERS_DGNLIBLIST defines search path(s) for Subsurface Filter dgnlib
# files. The filters can be used in the Extract Utilities from Graphics option.
CIVIL_SUBSURFACE_FILTERS_DGNLIBLIST > $(CIVIL_ORGANIZATION_STANDARDS)Dgnlib/Feature Definitions/Drainage and Utilities Features Annotations $(CIVIL_FILENAME).dgnlib
#-----

```

```

#=====
# Survey Files and Chains
#=====
# CIVIL_SURVEY_FILES_FOLDER overrides the location where survey import and export tools
# read definition files such as Leica FRT files and PrintfPC.exe files.
# By default this variable is NOT used and the definition files are

```

read from the \Program Files\ folder.

CIVIL_SURVEY_USERTIW_FOLDER overrides the location where survey import tools
reads the TIW files. By default this variable is NOT used and
the TIW files are read from the \Program Files\ folder.

```
CIVIL_SURVEY_FILES_FOLDER      = $(CIVIL_ORGANIZATION_STANDARDS)Dgnlib/Survey/  
CIVIL_SURVEY_USERTIW_FOLDER    = $(CIVIL_ORGANIZATION_STANDARDS)Dgnlib/Survey/  
#-----
```

```
#=====
# Profile and Superelevation View Exaggeration Values
#=====
# * _EXAGGERATION_VALUES defines a list of exaggeration values that are available in the View Attributes menu.
```

* _SET_DEFAULT_EXAGGERATION defines the default exaggeration value from the list
of available values used when a view is opened.

* _SKIP_DEFAULT_EXAGGERATION - If set to 1, the view is opened with a 1:1
exaggeration and the default exaggeration is ignored.

```
CIVIL_EXAGGERATION_VALUES      = 1,2,5,10,20,50,100  
CIVIL_SET_DEFAULT_EXAGGERATION = 10  
_CIVIL_SKIP_DEFAULT_EXAGGERATION = 0
```

```
CIVIL_SUPER_EXAGGERATION_VALUES = 100,200,500,1000,2000,5000,10000  
CIVIL_SET_SUPER_DEFAULT_EXAGGERATION = 5000  
_CIVIL_SKIP_SUPER_DEFAULT_EXAGGERATION = 0
```

```
# CIVIL_PROFILE_HORIZONTAL_GEOMETRY_INFO defines default behavior for displaying the  
# horizontal geometry information along in the profile view and superelevation views.  
# CIVIL_PROFILE_HORIZONTAL_GEOMETRY_HTTPS defines default behavior for displaying stations  
# at horizontal control points along the bottom of profile and superelevation views.  
# CIVIL_PROFILE_STATION_LOCK_INTERVAL defines the default interval for the  
# stationing displayed along the bottom of profile and superelevation views.  
CIVIL_PROFILE_HORIZONTAL_GEOMETRY_INFO = Enabled  
CIVIL_PROFILE_HORIZONTAL_GEOMETRY_HTTPS = Enabled  
CIVIL_PROFILE_STATION_LOCK_INTERVAL = 100  
#-----
```

```
#=====
# Stroking Tolerance Settings for Survey and Corridor Modeling
#=====
# These variables define how often to compute a point or template drop interval  
# along a tangent, profile, or curve. The Linear Stroking tolerance is the maximum  
# distance along a tangent. Extra points are added along profiles and curves based  
# on a chord offset from the profile or curve.  
# Refer to the Product Help for additional details.  
#
```

The four variables that begin with CIVIL_SURVEY are optional.
If these variables are set, these values will be used for Survey Terrain Model only
creation overriding the default Civil variables set for Survey and Corridor Modeling
Units are in master units (feet or meters)
#

```
%if $(Units) == "Metric"  
CIVIL_DEFAULT_LINEAR_STROKING      = 2.5  
CIVIL_DEFAULT_PROFILE_STROKING     = 0.02  
CIVIL_DEFAULT_CURVE_STROKING       = 0.02  
# CIVIL_SURVEY_STROKE_TOLERANCE_LINEAR = 30  
# CIVIL_SURVEY_STROKE_TOLERANCE_CURVE = 0.02  
%else  
CIVIL_DEFAULT_LINEAR_STROKING      = 10.0  
CIVIL_DEFAULT_PROFILE_STROKING     = 0.07  
CIVIL_DEFAULT_CURVE_STROKING       = 0.07  
# CIVIL_SURVEY_STROKE_TOLERANCE_LINEAR = 100.0  
# CIVIL_SURVEY_STROKE_TOLERANCE_CURVE = 0.05  
%endif  
#-----
```

```
#=====
# Default Best Fit Settings
#=====
# These variables define the best fit parameters that are used to calculate the  
# best fit profile when the 'Create 3D Automatically' option on the  
# Feature Definition Toggle bar is enabled.
```

These settings are NOT used by the 'Define Profile by Best Fit' geometry tool. That
tool has its own settings that are defined interactively through the graphical interface.

```
%if $(Units) == "Metric"  
CIVIL_DEFAULT_BEST_FIT_UPPER_ENVELOPE = 2  
CIVIL_DEFAULT_BEST_FIT_LOWER_ENVELOPE = -.5  
CIVIL_DEFAULT_BEST_FIT_CREST_LENGTH = 300  
CIVIL_DEFAULT_BEST_FIT_SAG_LENGTH = 300  
CIVIL_DEFAULT_BEST_FIT_MINIMUM_LENGTH = 50  
%else  
CIVIL_DEFAULT_BEST_FIT_UPPER_ENVELOPE = 5
```

```

CIVIL_DEFAULT_BEST_FIT_LOWER_ENVELOPE = -1
CIVIL_DEFAULT_BEST_FIT_CREST_LENGTH  = 1000
CIVIL_DEFAULT_BEST_FIT_SAG_LENGTH    = 1000
CIVIL_DEFAULT_BEST_FIT_MINIMUM_LENGTH = 150
%endif
#-----

#-----
# Civil Terrain Settings
#-----
# These variables define filtering when importing high density terrain data that
# contains many points such as DWG Contour mapping. The filtering looks at 3 points.
# If the distance between points 1 & 3 is less than the Filter Maxgap value, then
# point 2 is evaluated to see if it is offset from a line connecting points 1 & 3
# by less than the Filter Tolerance value. If it is then it is removed.
#
# These variables are not enabled by default. They should only be enable when required
# on a project by project basis that has terrain data in DWG format.

# CIVIL_DTM_LINestring_FILTER_TOLERANCE = 0.05
# CIVIL_DTM_LINestring_FILTER_MAXGAP   = 0.5
#-----

#-----
# Cross Section Settings
#-----
# CIVIL_CROSSSECTION_STACK_TOP_DOWN set to TRUE causes cross sections to be created
# from the top to the bottom of the sheet. When set to FALSE or not defined cross
# sections are created in the default method from the bottom to the top of the sheet.
CIVIL_CROSSSECTION_STACK_TOP_DOWN      = FALSE

# CIVIL_CROSSSECTION_REVERSE_STATION_ENABLE set to TRUE enables an option on the Create
# Drawing dialog to create cross sections in a reverse station order. If this variable
# is not defined or is defined as FALSE the option does not appear on the dialog
# When the Reverse Station Order option is selected on the Create Drawing dialog, the
# highest station cross section will appear first and the lowest station will appear last.
CIVIL_CROSSSECTION_REVERSE_STATION_ENABLE = FALSE

# Units are in Sheet master units(feet or meters)
# NOTE: ALL 5 variables must be set for them to be used.
#
# CIVIL_CROSSSECTION_RT_TO_LT_SPACING - If multiple cross sections can fit in the same
# row moving from left to right, this variable defines the horizontal spacing between
# the adjacent cross section boundaries.

# CIVIL_CROSSSECTION_TOP_TO_BOT_SPACING - If multiple sections can fit in the same
# column moving from bottom to top, this variable defines the vertical spacing between
# the adjacent cross section boundaries.

# CIVIL_CROSSSECTION_SIDE_MARGIN - Each cross section is tested in the horizontal direction
# to determine if it will fit on the sheet and still allow this variable to be met. This
# distance is measured from the right edge of the cross section clipping boundary to the
# right edge of the sheet model edge. If the computed distance is less than this variable,
# a new cross section sheet model will be generated for the next cross section.

# CIVIL_CROSSSECTION_TOP_MARGIN - Defines the distance measured from the top edge of the
# cross section clipping boundary to the top edge of the sheet model edge.
# If CIVIL_CROSSSECTION_STACK_TOP_DOWN is TRUE, this variable defines the starting location
# of the first cross section at the top of the sheet.
# If CIVIL_CROSSSECTION_STACK_TOP_DOWN is FALSE, this variable defines the top margin.
# If there is not sufficient space for a cross section to fit inside the margin, a new
# column or sheet of cross sections is started.

# CIVIL_CROSSSECTION_BOT_MARGIN - Defines the distance measured from the bottom edge of the
# cross section clipping boundary to the bottom edge of the sheet model edge.
# If CIVIL_CROSSSECTION_STACK_TOP_DOWN is FALSE, this variable defines the starting location
# of the first cross section at the bottom of the sheet.
# If CIVIL_CROSSSECTION_STACK_TOP_DOWN is TRUE, this variable defines the bottom margin.
# If there is not sufficient space for a cross section to fit inside the margin, a new
# column or sheet of cross sections is started.

%if $(Units) == "Metric"
CIVIL_CROSSSECTION_RT_TO_LT_SPACING = 0.050
CIVIL_CROSSSECTION_TOP_TO_BOT_SPACING = 0.045
CIVIL_CROSSSECTION_SIDE_MARGIN      = 0.025
CIVIL_CROSSSECTION_TOP_MARGIN       = 0.035
CIVIL_CROSSSECTION_BOT_MARGIN       = 0.035

%else
CIVIL_CROSSSECTION_RT_TO_LT_SPACING = 0.16667
CIVIL_CROSSSECTION_TOP_TO_BOT_SPACING = 0.16667
CIVIL_CROSSSECTION_SIDE_MARGIN      = 0.08333
CIVIL_CROSSSECTION_TOP_MARGIN       = 0.12500
CIVIL_CROSSSECTION_BOT_MARGIN       = 0.12500
%endif
#-----

```

```

=====
# Civil Model Upgrade Options
=====
# Two configuration variables control upgrading options.
#
# When the CIVIL_UPGRADE_PROMPT_OFF variable is set equal to 1, it will hide
# the upgrade prompt and automatically upgrade files with no prompting.
#
# CIVIL_OPEN_OLD_READONLY on its own will do nothing. It requires the
# CIVIL_UPGRADE_PROMPT_OFF configuration variable also be set. However, when
# both variables are set, the upgrade prompt will be hidden and the file
# will be opened as read-only.

#CIVIL_UPGRADE_PROMPT_OFF      = 1
#CIVIL_OPEN_OLD_READONLY      = 1
#-----

=====
# Civil Annotation Sight Distance Computation
=====
%if ${Units} == "Metric"
    CIVIL_ANNOTATION_SIGHTDISTANCE_EYEHEIGHT = 1.08
    CIVIL_ANNOTATION_SIGHTDISTANCE_OBJECTHEIGHT = 0.60

%else
    CIVIL_ANNOTATION_SIGHTDISTANCE_EYEHEIGHT = 3.50
    CIVIL_ANNOTATION_SIGHTDISTANCE_OBJECTHEIGHT = 2.00
%endif
#-----

=====
# Rail Dimensions
=====
%if ${Units} == "Metric"
    CIVIL_RAIL_CENTER_CENTER_DISTANCE = 1.500
    CIVIL_RAIL_INSIDE_INSIDE_DISTANCE = 1.435

%else
    CIVIL_RAIL_CENTER_CENTER_DISTANCE = 4.921
    CIVIL_RAIL_INSIDE_INSIDE_DISTANCE = 4.708
%endif
#-----

```

```

=====
# Civil Annotation Computed Prefix Override Names #EDITED
=====
CIVIL_USE_CUSTOM_POINT_LABELS = 1
#CIVIL_LABEL_SCS      = SCS
#CIVIL_LABEL_SRS      = SRS
#CIVIL_LABEL_ST       = T
#CIVIL_LABEL_SC       = SC
#CIVIL_LABEL_TS       = S
#CIVIL_LABEL_CS       = CS
#CIVIL_LABEL_PRC      = PRC
#CIVIL_LABEL_PCC      = CC
#CIVIL_LABEL_PC       = C
#CIVIL_LABEL_PT       = T
#CIVIL_LABEL_POT      = POT
#CIVIL_LABEL_START    = START
#CIVIL_LABEL_END      = END
#CIVIL_LABEL_POLY     = POLY
#CIVIL_LABEL_VHP      = VHP
#CIVIL_LABEL_VLP      = VLP
#CIVIL_LABEL_VPC      = PVC
#CIVIL_LABEL_VPT      = PVT
#CIVIL_LABEL_VPI      = PVI
#CIVIL_LABEL_VPI_ARC  = VPI_ARC
#CIVIL_LABEL_VPI_PARABOLA = PVI
#CIVIL_LABEL_HPI      = HPI
#CIVIL_LABEL_HPI_ARC  = HPI_ARC
#CIVIL_LABEL_HPI_SPIRAL = HPI_SPIRAL
#CIVIL_LABEL_EQN      = EQN
#CIVIL_LABEL_EQNAH    = EQNAH
#CIVIL_LABEL_EQNBK    = EQNBK
#-----

```

```

=====
# Overhead line Settings
=====
# This variable defines the standards file used by the Overhead Line tools.

OVERHEADLINE_DESIGNSTANDARDS_FILE = $(CIVIL_ORGANIZATION_STANDARDS)Overheadline/${UNITS}OHLStandards.odr

OVERHEADLINE_SICAT_SETTINGSDIR_DIR = $(CIVIL_ORGANIZATION_STANDARDS)Overheadline/
OVERHEADLINE_SICAT_WORKSPACEDIR_DIR = $(CIVIL_ORGANIZATION_STANDARDS)Overheadline/
OVERHEADLINE_SICAT_WORKSETDIR_DIR = $(CIVIL_ORGANIZATION_STANDARDS)Overheadline/
#-----

```

MS_PLTDLG_ALLOW_FORM_SIZE_EDIT = 1

```
#=====
# Scale Models App
#=====
# APPLICATION: Scale Models
# KEYIN: ScaleModels Start
_SM_ADDIN_PATH                                = $(CIVIL_ORGANIZATION_STANDARDS)Apps/Migration Utils/Scale Models

MS_ADDINPATH                                  < $_SM_ADDIN_PATH)/

MS_ADDIN_DEPENDENCYPATH                      < $_SM_ADDIN_PATH)

%if exists ($_SM_ADDIN_PATH)/ScaleModels.dll)
  MS_DGNAPPS                                  < $_SM_ADDIN_PATH)/ScaleModels.dll
%endif
#-----
```